




Fitting Instructions

JOHN DEERE 6 & 7 SERIES



Operation and adjustment: iPaddock Typhoon Feed Drum

*(Right and left refer to as facing **forwards**)*

The iPaddock Typhoon for John Deere fronts has been tailor designed specifically to maximize performance in these fronts. The cluster of iPaddock's patented Paddle Flights, combined with the aggressive long throw finger pattern and the reduced barrel diameter, maximizes smooth flow and minimizes the dead zone coming off the side mats into the feed drum on these fronts.

Retractable Finger Timing

Adjust the finger timing by rotating the original timing lever at the right hand end of the adaptor, as per the John Deere instructions.

NOTE: It is important to fine tune the finger timing with small incremental adjustments until you find the optimum timing to suit the crop conditions.

The recommended initial position for the retractable fingers on the iPaddock Typhoon is for the fingers to reach maximum extension around 45 degrees forward from top dead center, allowing them to be fully retracted by the time they are coming up the back side of the rotation, which minimizes the chance of catching crop and creating repeats over the drum.

If you experience repeating around the drum, this is generally improved by advancing the finger timing. This is done by rotating the timing lever anti-clockwise. Feeding issues are most commonly a result of excessively slow finger timing.

Light and Droughted Crops

In very short and light crops it may be an advantage to slow the finger timing (i.e. rotate the timing lever clockwise) to maximize the length of the fingers at the bottom of the stroke.

Canola and Bulky/Fluffy Crops

Advancing the finger timing (i.e. rotating the timing lever anti-clockwise) may be useful in crops that sit up very high in the front. Modifications to the top cross auger, including adding rubber paddles in the centre, can also assist in pushing high or

Installing iPaddock Typhoon for JD 6&7 series front

*(Right and left refer to as facing **forwards**)*

fluffy crop down for collection by the iPaddock Typhoon feed drum.

Remove the Original Feed Drum:

Remove the adaptor and original feed drum from the front according to the John Deere instruction manual.

Remove the inspection covers, retractable fingers, drive end and idle end shafts, crankshaft and bearings from the original drum, ready for re-use on your new iPaddock Typhoon drum.

NOTE: Inspect the bearings and replace if required before installing into the iPaddock Typhoon feed drum.

Assembly and Installation of the iPaddock Typhoon Feed Drum:

Your new iPaddock Typhoon comes supplied with a full new set of fingers, plus some new finger holders. Depending on the age and model of your John Deere front, you may not need all of the fingers and holders supplied.

- Bolt the original cast flanges to the outer ends of the iPaddock Typhoon. Torque the retaining bolts as per the John Deere specifications.



- Assemble the original hex clamped ends to the original crankshaft, inside the iPaddock Typhoon drum.


NOTE: Later model 6 series and 7 series fronts have a longer crankshaft, and may require the corners of the end clamps to be trimmed using a cutting disc to avoid contacting inside the drum. This allows the maximum number of fingers to be used in the iPaddock Typhoon feed drum.

CAUTION: Ensure a minimum gap of 8mm between the clamp end and the inside of the drum to avoid the risk of fire or damage.




- Install the new retractable fingers (supplied) to the crankshaft using the original and supplied finger holders.

NOTE: the original bent metal finger retainers are not required with the iPaddock Typhoon.



- Check that all internal fasteners are tight and torqued as per John Deere specifications.



- Install the iPaddock Typhoon into the John Deere adaptor and fit the adaptor back into the front using the reverse of the removal steps.
- Ensure that the draper mats have sufficient clearance either side of the iPaddock Typhoon feed drum. Trim the mats and/ or adjust the position of the decks if required to achieve sufficient clearance.



- Install the original inspection covers onto the iPaddock Typhoon.



IMPORTANT: The correct orientation of the retractable finger timing mechanism is critical for correct performance of your iPaddock Typhoon feed drum. When positioned correctly, the fingers should be fully extended near the forward horizontal position when the John Deere timing adjustment lever is in mid range. This must be checked once the iPaddock Typhoon has been installed.

IMPORTANT: RISK OF FIRE OR DAMAGE. Check that all moving parts have sufficient clearance when rotating to avoid any contact. Rotate the drum manually prior to startup to confirm that there are no points of contact.

Canadian Manual: Patent Number 3054577
United States Manual: Patent Number 11317563

The logo for Thunderstruck AG Equipment, featuring the brand name in a bold, sans-serif font with a stylized lightning bolt graphic.

Warranty Disclaimer

Thunderstruck Ag Equipment is a distributor of the products we sell and does not provide any direct warranty coverage. All warranty claims and coverage are provided solely by the product's manufacturer, according to their specific terms and conditions.

If you experience a product issue and believe it may be covered under warranty, please contact one of our sales representatives. We're happy to assist you in coordinating your claim with the appropriate manufacturer.

The logo for i-Paddock, featuring a stylized green leaf icon followed by the brand name in a bold, sans-serif font.

Warranty Statement

The i-Paddock Typhoon comes with a 12-month manufacturer's warranty. This warranty typically covers defects in materials and workmanship under normal use.